

WiFi Tellur Smart Devices Manual

Works with Alexa or Google Home

Simplified steps to install App on your smart device and pair with Amazon Alexa using Tellur Smart App on App Store / Android Market and Alexa Home skills menu



Download and install the Tellur Smart App for either iOS or Android devices.



App Store

vou live in.





Google Play Once downloaded, the app will ask you to register your device. Enter your phone number or email which

If phone number selected you will receive a text with a registration code. If you choose email vou will then create a password.

makes you feel comfortable and select the country

Input the Registration Code you received via text if phone method has been used or create password if email method



Adding a New Device

Turn on power of device

- being paired and make sure
- Open App and Click "+" to
- Select WiFi network and input password of WiFi then.
- Once connected the App will prompt the connection then you can rename the device or just click "done"



 Once App is installed on your device and you have added your smart device to your app you will be able

Next step is to sync with Alexa or echo:

Select "Skills" in home menu of Amazon Alexa




The second of the second of

5. Then you need to input your account and

6. Tellur Smart App has been skilled with

Branswer, close inc.

password that you registered in Tellur Smart 3. Type (Smart Life) on search window and find



(At let

The State Committee Commit

Section and the section of

4. Click on the App (Smart Life) and press Enable 1.Go to Home menu on Alexa App to activate "smart life".



Now you finish the Alexa Link.



Smart devices can be connected using two modes: EZ

EZ represents the easiest way of connecting and

enabling a smart device. You will need to have the

device, active wireless network through with login

password and Tellur Smart APP installed on a

AP mode can be used to configure and enable a smart

button for 5 seconds until indicator light flashes

representing successful reset; Indicator light

quickly flashes (2 times per second), representing

Indicator light slowly flashes (one time per 3

seconds), representing AP mode; Under EZ mode.

long press reset button for 5 seconds until indicator

light slowly flashes, representing switching to AP

Quick light flashes (4 times per second), represent

device first with the smartphone / tablet and later on

Reset heater, oil heater etc. Long press reset

Why failed to add device?

. Please check whether device is powered on

4. Check routers or related: If router is dual-bar

Wireless mode cannot be 11n only

normally you can manually press on the device to

get it ready. Please refer to "Product Instructions"

Notice Each time to add device, reset Wi-Fi to get

device ready for configuration and make sure

router, select 2.4G network and add device. You

also need to enable router's broadcasting function.

WPA2-PSK and authorization type as AES, or set

Set up wireless router: Set encryption method as

Don't use Chinese to name router Wi-Fi.To stay strong

Wi-Fi signal, please keep device and router within

Whether connected devices have reached the

maximum number of router's connections. If so, please

try by turning off the Wi-Fi connection of some device.

Remove the device from the filter list and make sure

that router is not prohibiting device from connection

5. Make sure the password entered in App is correct

Whether phone is connected via Wi-Fi;

router is working properly

EZ and AP connection modes:

smartphone / tablet.

to the Wi-Fi network

How to reset device?

quick connect mode.

mode and vise versa

please repeat the steps above

How to add device under EZ mode?

1. Make sure that indicator light or light quickly

 What you need to get started Phone has connected to Wi-Fi router and been

Before using Google Home to control your devices. make sure you meet the following conditions

Tap "Add device" in app and enter correct Wi-F A Google Home device, or Android phone with Google Assistant.

pass-word. Touch to search device around: In the device list, select and add the device. Latest Google Home app.

 Latest Google app [Android only] How to add device under AP mode? A Google account

 Make sure that indicator light quickly flashes o The device display language must be set to

2 Tap "Add device" in App and then "AP mode" in brightfun app and a related account. the top right corner. Connect to device hotspot fire Smart devices.

Tap "Next" to add device. Add devices in Tellur Smart App (Refer to App

When adding device for the first time, it requires that device and phone need to be under the same Wi-Fi

environment. After successfully adding device, you can remote control device with 2G/3G/4G network How can I share my device with family?

2. Reset smart light. Turn off light first, Switch Open App. go to "Profile" > "Device Sharing" > interval cannot exceed 10 seconds), flashing lights "Sharings Sent", tap "Add Sharing", then you can represents successful reset; if no light flashes, share the device with the added family members.

Can I control device with 2G/3G/4G network?

able to connect to Internet:

light slowly flashes:

and then Wi-Fi

Open App. go to "Profile" > "Device Sharing" > represent AP mode: Under EZ mode, turn off lights and then switch light with the steps: Switch on - off - on - off - on (time interval cannot exceed 10 seconds). Light begins to slowly flash, representing that it has switched to AP mode and vise versa.

Quick Guide of Using Google Home to Control . Register a Tellur Smart account and sign in the Smart Devices

Open the Tellur Smart app, tap "Register" to register an account then sign in the app.

Add device and change device's name IRefer to

Sign in with the Tellur Smart account, add the device, then change device name to a easily recognized word or phrase, like "bedroom light".

Link account in Home Control

You can skip this part if you've already add some devices to your Tellur Smart account, and in the

meantime the devices name are easily recognized. Download Tellur Smart App

You can scan the QR code below to download the Tellur Smart App:

How can I manage the devices shared by others?

"Sharings Received", then you can find the devices shared by other users. It also allows to add remarks to users or delete certain sharings by long pressing or You can also search Tellur Smart App in either App Store or Google Play to install the app.

app (Refer to App Instruction)

App Instruction)

1.Tap "Home Control" in the hamburger menu on the Google Home app's home page, then tap "+"

 Ok Google, turn on/off bedroom light. Ok Google, set bedroom light to 50 percent Ok Google, brighten bedroom light, CC Street or ...

C revenue

listed in the Home Control page.

Smart Life account's region, type your Tellur Smart

account and password, then tap "Link Now", After

you assign rooms for devices, your devices will be

2. Find in the list. In the new window, select your

Ok Google, dim bedroom light.

t agent - - 1 1 minut

Now you can control your smart devices through

the supported voice commands are as below-

Google Home. Take bedroom light as the example.

Ok Google, set bedroom light to red.

Declaration of conformity

We. ABN SYSTEMS INTERNATIONAL S.R.L.. | We. ABN SYSTEMS INTERNATIONAL S.R.L. Bucharest, Sector 1, Marinarilor street, nr. 31, we Bucharest, Sector 1, Marinarilor street, nr. 31, we declare on own responsibility that the product below:

not have a negative impact on the environment and

corresponds to the standards stated in the

The product is in compliance with the followin

manufacturer's declaration of conformity.

RED - 2014/53/EU

EN 300 328 (Radio)

RoHS - 2011/65/EU

Name: George Barbu

Product description Brand Product code WiFi Smart Bulb E27, Tellur TLL331001 10W. white/warm. WiFi Smart Bulb E27. | Tellur | TLL331011 10W. white/warm/RGB. It does not endanger life, health, work safety, does

> It does not endanger life, health, work safety, does not have a negative impact on the environment and corresponds to the standards stated in the

Applied standards: EN 62479 (Health) The product is in compliance with the following EN 60950-1 (Safety) EN 301 489-1/-17 [EMC

EN 301 489-17 V3.2.0 [2017-03] EN 300 328 V2.1.1 (2016-11) (Radio)

RoHS - 2011/65/EU



declare on own responsibility that the product below

1031
1041
1051

standards and / or other normative documents: manufacturer's declaration of conformity.

standards and / or other normative documents

RED - 2014/53/EU Applied standards

EN 60950-1:2006+A2:2013 (Safety

The product bears CE mark, applied in 2018 EN 301 489-1 V2 2 0 (2017-03) (EMC)

Function: General manager Bucharest, 02-05-2018

The product bears CE mark, applied in 2018

Name: George Barbu

Function: General manager

Bucharest, 02-05-2018







/ Disposal and recycling information

The crossed-out wheeled-bin symbol on your

that all electronic products and batteries must be

taken to separate waste collection points at the end of

the normal waste stream with household garbage. It

is the responsibility of the user to dispose of the

equipment using a designated collection point or

electronic equipment (WEEE) and batteries according

to local laws. Proper collection and recycling of your

protects human health and the environment,

improper handling, accidental breakage, damage,

and/or improper recycling at the end of its life may be

equipment helps ensure EEE waste is recycled in a

manner that conserves valuable materials and

service for separate recycling of waste electrical and

their working lives; they must not be disposed of in

product, battery, literature or packaging reminds you