## FM transmitter T844 User manual

## Instructions:

- Insert the FM modulator into the lighter holder of your car or in a power port
- Set the radio to the desired FM frequency, then set the modulator on the same frequency using the buttons on the unit or the remote control
- Insert the memory stick into the USB port or SD card on the card slot (if present), will automatically start playing the songs on the device.
- This product also supports other devices: MP3 player, CD-DVD player, using the supplied audio cable with the product. One end of the cable must be plugged into the FM modulator, and at the other end the MP3 player, CD-DVD player. Songs stored on these devices will be played on the car radio. All playback controls are functional on the device not on the FM modulator.

## Operating guide:

	•	
Operating Guide	FM Transmitter	Remote control
1、Switch on / off	Press the "PLAY" button: to start the music to stop, press again PLAY	Press M
2、How to change the volume	Long press on the button "" - volume increase  Long push on button "" - decrease volume	Press "VOL+"" increase volume; press "VOL-" decrease volume
3.  How to change the frequency	Press "CH": then press "" – increase frequency Press "CH": then press "" - decrease frequency	Press the button "CH+": increase 0.1MHZ Press the button "CH-": decrease 0.1MHZ or press "CH" and then press the wanted frequency no, press "CH+" to confirm
4、How do you choose music	Short press on "M": for the next song Short press on "M": for the previous song	Press the button "NEXT": for the next song; Press the button "PREV "for the previous song Or press the no of the wanted song
5. EQ setting	Nonsupport	Press "EQ" to select the wanted EQ
6. Change the repeat mode	Long press on play / pause button	Nonsupport
		ARN Systems International

## ABN Systems International

- Str. Marinarilor, nr.29 Sector 1, Bucuresti, Romania
- 004.021.233.09.95
- office@tellur.com
- www.tellur.com